




# PlayStation One Lower Case Replacement

This will guide you in replacing of your PlayStation One's Lower Case.

Written By: trickster



## Step 1 — Upper Case



- Remove all cables plugged into the PlayStation.

## Step 2



- Flip over the PlayStation and remove the six screws from the bottom.

## Step 3



- Flip the PlayStation back.

⚠ There are no screws holding EVERYTHING inside the PlayStation so better hold it like a burger while flipping.


## Step 4



- Lift up and remove the upper case.



## Step 5 — Lens




- Disconnect the ribbon cable and wired cable connectors.
- Take extreme care when disconnecting ribbon cable from motherboard. Tears extremely easy.

## Step 6 — Mother Board



- remove the metal plate



## Step 7



- remove the mother board by lifting the back.

**i** if you're having a hard time removing it, use your nail and lift the second controller port.

## Step 8 — Lower Case



- Remove the metal case.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 04:04:14 AM.